WD0754W8(E/N/S/V/W) WD0752W8(E/N/S/V/W) WD0754Y8(E/N/S/V/W) WD0752Y8(E/N/S/V/W)

Washing Machine user manual

۲



()

100% Recycled Paper

This manual is made with 100% recycled paper.

imagine the possibilities

Thank you for purchasing this Samsung product. To receive a more complete service, please register your product at

www.samsung.com/register



۲

features of your new samsung washing machine

Your new washing machine will change the way you feel about doing laundry. With its Bubble wash function, your new Samsung washing machine has all the benefits to make washing laundry easy and pleasant.

• Bubble Wash

Samsung's effective Eco Bubble delivers cleanliness with fabric care.

• Washing and drying with one button

Enjoy convenient non stop washing and drying managing. 4 different special drying programs can be selected to perform the whole wash cycle including the drying cycle using one button.

• Cupboard(standard program), Low temp drying, Iron, Time Drying (30min ~ 270mins) Those drying programs also can be operated independently of washing programs.

Air Wash

The Air Wash system helps to deodorize unpleasant smells and sanitizes the laundry, a benefit of its unique air-washing mechanism.

- Air-washable : Woolen coats, cotton/down jumpers, sweaters, suits, pillows, cushions, needlework dolls
- Not applicable : leather, silk, velvet, electric blankets, stained laundry

Quick Wash

()

No time to waste! Quick Wash program can help your busy life - now you can wash your favourite clothes (up to 2Kg) in 15 minutes!

• Quiet Drive Motor

Samsung's unique Quiet Drive Motor works without belts or gears, helping to reduce vibration and making the washer quiet and durable.

Drum Clean

Using Drum Clean helps to keep washing machine clean even without any chemical detergent or bleach. Keep your drum clean and odourless with specialized cleaning program.

Baby Care

Your Samsung washing machine includes wash programs that add protection to the clothing of children with sensitive skin. These programs help to reduce skin irritation in children by minimizing detergent residue. In addition, these programs classify laundry into various types and the wash is performed according to the laundry characteristics so that children's clothes feel refreshingly clean whenever they are put on.

2 features

Wool Certified

The machine has been tested and passed the required Woolmark Company specification for machine washable wool products. This mark is the upgraded certification better than the existing Woolmark, which guarantees not only washing performance but also fabric care for wool products.

۲

Fabrics should be washed according to the instructions on the garment label as specified by Woolmark and Samsung.

Delay End

Delay a cycle for up to 19 hours in one-hour increments and increase the convenience of using your washing machine especially when you have to go out.

Child Lock

The Child Lock function helps to ensure that curious little hands are kept out of your washing machine. This safety feature stops your children from playing with the operation of the washing machine, and alerts you when it is activated.

This manual contains important information on the installation, use, and care of your new Samsung washing machine. Refer to it for descriptions of the control panel, instructions on how to use the washing machine, and tips for making the most of its state-of-the-art features and functions. The "Troubleshooting and information codes" section on page 39 tells you what to do if something goes wrong with your new washing machine.

۲

۲

satety information

Congratulations on your new Samsung washer. This manual contains important information on the installation, use and care of your appliance. Please take time to read this manual to take full advantage of your washer's many benefits and features.

WHAT YOU NEED TO KNOW ABOUT SAFETY INSTRUCTIONS

Please read this manual thoroughly to ensure that you know how to safely and efficiently operate the extensive features and functions of your new appliance and retain it at a safe place near the appliance for your future reference. Use this appliance only for its intended purpose as described in this instruction manual.

Warnings and Important Safety Instructions in this manual do not cover all possible conditions and situations that may occur. It is your responsibility to use common sense, caution, and care when installing, maintaining, and operating your washer.

Because these following operating instructions cover various models, the characteristics of your washer may differ slightly from those described in this manual and not all warning signs may be applicable. If you have any questions or concerns, contact your nearest service center or find help and information online at www.samsung.com.

IMPORTANT SAFETY SYMBOLS AND PRECAUTIONS

	Hazards or unsafe practices that may result in severe personal injury, death and/or property damage.
	Hazards or unsafe practices that may result in personal injury and/or property damage .
	To reduce the risk of fire, explosion, electric shock, or personal injury when using your washer, follow these basic safety precautions:
	Do NOT attempt.
\mathbf{x}	Do NOT disassemble.
Ø	Do NOT touch.
*	Follow directions explicitly.
	Unplug the power plug from the wall socket.
Ē	Make sure the machine is grounded to prevent electric shock.
	Call the service centre for help.
Ø	Note

What the icons and signs in this user manual mean:

These warning signs are here to prevent injury to you and others. Please follow them explicitly.

After reading this section, keep it in a safe place for future reference.



Read all instructions before using the appliance.

As with any equipment using electricity and moving parts, potential hazards exist. To safely operate this appliance, become familiar with its operation and exercise care when using it.

۲

۲

Do not let children (or pets) play on or in your washing machine. The washing machine door does not open easily from the inside, and children may be seriously injured if trapped inside.

۲

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

If the plug (power supply cord) is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

This appliance should be positioned to be accessible to the power plug, the water supply tabs and the drain pipes.

For washing machines with ventilation openings in the base, ensure that the opening is not obstructed by carpet or any other obstacles.

Use the new hose-sets and old hose-sets should not be reused.

safety information _5

۲

۲

safety information

A SEVERE WARNING SIGNS FOR INSTALLATION



۲

The installation of this appliance must be performed by a qualified technician or service company.

 (\bullet)

- Failure to do so may result in electric shock, fire, an explosion, problems with the product, or injury.

The appliance is heavy, take care upon lifting it

Plug the power cord into an AC 220-240V / 50Hz wall socket or higher and use the socket for this appliance only. In addition, do not use an extension cord.

- Sharing a wall socket with other appliances using a power strip or extending the power cord may result in electric shock or fire.
- Ensure that the power voltage, frequency and current are the same as those of the product specifications. Failure to do so may result in electric shock or fire. Plug the power plug into the wall socket firmly.

Remove all foreign substances such as dust or water from the power plug terminals and contact points using a dry cloth on a regular basis.

- Unplug the power plug and clean it with a dry cloth.
- Failure to do so may result in electric shock or fire.

Plug the power plug into the wall socket in the right direction so that the cord runs towards the floor.

 If you plug the power plug into the socket in the opposite direction, the electric wires within the cable may be damaged and this may result in electric shock or fire.

Keep all packaging materials well out of the reach of children, as packaging materials can be dangerous to children.

- If a child places a bag over its head, it may result in suffocation.

When the appliance or power plug or power cord is damaged, contact your nearest service centre.

This appliance must be properly grounded.

Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.

- This may result in electric shock, fire, an explosion, or problems with the product
 Never plug the power cord into a socket that is not grounded correctly and make sure
- that it is in accordance with local and national codes.

Do not install this appliance near a heater, inflammable material.

Do not install this appliance in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops).

Do not install this appliance in a location of low temperature - Frost may cause tubes to burst

Do not install this appliance in a location where gas may leak.

- This may result in electric shock or fire.

Do not use an electric transformer.

- It may result in electric shock or fire.

Do not use a damaged power plug, damaged power cord or loose wall socket.

- This may result in electric shock or fire.

Do not pull or excessively bend the power cord. Do not twist or tie the power cord.

6_ safety information

۲

Do not hook the power cord over a metal object, place a heavy object on the power cord, insert the power cord between objects, or push the power cord into the space behind the appliance.

- This may result in electric shock or fire.

Do not pull the power cord, when unplugging the power plug.

- Unplug the power plug by holding the plug.
- Failure to do so may result in electric shock or fire.

Do not lay the power cord and tubes where you may fall over them.

۲

CAUTION SIGNS FOR INSTALLATION

This appliance should be positioned in such a way that it is accessible to the power plug.
 Failure to do so may result in electric shock or fire due to electric leakage.

Install your appliance on a level and hard floor that can support its weight.

 Failure to do so may result in abnormal vibrations, moves, noise, or problems with the product.

ARNING SEVERE WARNING SIGNS FOR USING



()

If the appliance is flooded, Turn off the water & power supply immediately and contact your nearest service centre.

- Do not Touch the power plug with wet hands
- Failure to do so may cause electric shock

If the appliance generates a strange noise, a burning smell or smoke, unplug the power plug immediately and contact your nearest service centre.

- Failure to do so may result in electric shock or fire.

In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power plug. Do not touch the appliance or power cord.

- Do not use a ventilating fan.
- A spark may result in an explosion or fire.

Do not let children play in or on the washer. In addition, when disposing of the appliance, remove the washer door lever.

- If trapped inside, the child may become trapped and suffocate to death.

Make sure to remove the packaging (sponge, styrofoam) attached to the bottom of the washer before using it.

safety information

- \Box Do not wash items contaminated with gasoline, kerosene, benzene, paint thinner, alcohol or other flammable or explosive substances.
 - This may result in electric shock, fire or an explosion.

Do not open the washer door by force while it is operating (high-temperature washing/ drying/spinning).

- Water flowing out of the washer may result in burns or cause the floor to be slippery.

This may result in injury.

- Opening the door by force may result in damage to the product or injury.

۲

Do not insert your hand under the washer.

- This may result in injury.

Do not touch the power plug with wet hands.

- This may result in electric shock.

Do not turn the appliance off by unplugging the power plug while an operation is in progress.

- Plugging the power plug into the wall socket again may cause a spark and result in electric shock or fire.

Do not let children or infirm persons use this washer unsupervised. Do not let children climb in the appliance

- Failure to do so may result in electric shock, burns or injury.

Do not insert your hand or a metal object under the washer while it is operating. - This may result in injury.

Do not unplug the appliance by pulling at the power cord, always grip plug firmly and pull straight out from the outlet.

- Damage to the cord may cause short-circuit, fire and/or electric shock

Do not attempt to repair, disassemble, or modify the appliance yourself.

- Do not use any fuse (such as cooper, steel wire, etc.) other than the standard fuse.
- When repairing or reinstalling the appliance is required, contact your nearest service centre.
- Failure to do so may result in electric shock, fire, problems with the product, or injury.

If the water supply hose comes loose from the Water tap and floods the appliance, unplug the power plug.

- Failure to do so may result in electric shock or fire.

Unplug the power plug when the appliance is not being used for long periods of time or during a thunder/lightning storm.

- Failure to do so may result in electric shock or fire.

8_ safety information

۲

۲

★

When the washer is contaminated by a foreign substance such as detergent, dirt, food waste, etc., unplug the power plug and clean the washer using a damp and soft cloth.
Failure to do so may result in discolouration, deformation, damage or rust.

۲

The front glass may be broken by a strong impact. Take care when using the washer.

- When the glass is broken, it may result in injury.

After a water supply failure or when reconnecting the water supply hose, open the Water Tap slowly.

Open the Water Tap slowly after a long period of non-use.

- The air pressure in the water supply hose or the water pipe may result in damage to a part or in water leakage.

If a drain error occurs during an operation, check if there is a draining problem.

- If the washer is used when it is flooded because of a draining problem, it may result in electric shock or fire due to electric leakage.

Insert the laundry into the washer completely so that laundry does not get caught in the door.

- If laundry gets caught in the door, it may result in damage to the laundry or the washer, or result in water leakage.

Ensure that the Water Tap is turned off when the washer is not being used.

- Ensure that the screw on the water supply hose connector is properly tightened.
- Failure to do so may result in property damage or injury.

Check if the rubber seal is not contaminated by foreign substances (waste, thread, etc). - If the door is not closed completely, it may result in water leakage.

Open the Water Tap and check if the water supply hose connector is firmly tightened and that there is no water leaking before using the product.

- If the screws or the water supply hose connector are loose, it may result in water leakage.

۲

۲

safety information

Do not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.

- This may result in electric shock, fire, problems with the product, or injury.

۲

Do not spray volatile material such as insecticide onto the surface of the appliance.

- As well as being harmful to humans, it may also result in electric shock, fire or problems with the product.

Do not place an object that generates a electromagnetic field near the washer. - This may result in injury due to a malfunction.

Since the water drained during a high-temperature wash or drying cycle is hot, do not touch the water.

- This may result in burns or injury.

Do not wash, spin or dry water-proof seats, mats or clothing (*) unless your appliance has a special program for washing these items.

- Do not wash thick, hard mats even if the washer mark is on the care label.
- This may result in injury or damage to the washer, walls, floor or clothing due to abnormal vibrations.
- * Woollen bedding, rain covers, fishing vests, ski pants, sleeping bags, diaper covers, sweat suits, and bicycle, motor cycle, car covers, etc.

Do not operate the washer when the detergent box is removed.

- This may result in electric shock or injury due to water leakage.

Do not touch the inside of the tub during or just after drying as it is hot.

- This may result in burns.

Do not insert your hand into the detergent box after opening it.

- This may result in injury as your hand may be caught by the detergent input device. Do not place any objects (such as shoes, food waste, animals) other than laundry into the washer.
- This may result in damage to the washer, or injury and death in the case of pets due to the abnormal vibrations.

Do not press the buttons using sharp objects such as pins, knifes, fingernails, etc.

- This may result in electric shock or injury.

Do not wash laundry contaminated by oils, creams or lotions usually found in skincare shops or massage clinics.

- This may result in the rubber seal becoming deformed and water leakage.

Do not leave metal objects such as a safety pin or hair pin, or bleach in the tub for long periods of time.

- This may cause the tub to rust.
- If rust starts appearing on the surface of the tub, apply a cleansing agent (neutral) to the surface and use a sponge to clean it. Never use a metal brush.

Do not use dry cleaning detergent directly and do not wash, rinse, or spin laundry contaminated by dry cleaning detergent.

- This may result in spontaneous combustion or ignition due to the heat of the oxidation of the oil.

Do not use hot water from water cooling/heating devices.

- This may result in problems with the washer.

۲

۲

۲

Do not use natural hand-washing soap for the washer.

- If it hardens and accumulates inside the washer, it may result in problems with the product, discolouration, rust or bad odors.

Do not wash large laundry items such as bedding in the washing net.

- Place socks and brassieres into the washing net and wash them with the other laundry.
- Failure to do so may result in injury due to abnormal vibrations.

Do not use hardened detergent.

- If it accumulates inside the washer, it may result in water leakage.

For washing machines with ventilation openings in the base, ensure that the opening is not obstructed by carpet or any other obstacles.

Make sure that the pockets of all clothing to be washed are empty.

- Hard, sharp objects, such as coins, safety pins, nails, screws, or stones can cause extensive damage to the appliance.

Do not wash clothing with large buckles, buttons, or other heavy metal.

MARNING SEVERE WARNING SIGNS FOR CLEANING

Do not clean the appliance by spraying water directly onto it.

- Do not use benzene, thinner or alcohol to clean the appliance.
- This may result in discolouration, deformation, damage, electric shock or fire.

Before cleaning or performing maintenance, unplug the appliance from the wall socket.

- Failure to do so may result in electric shock or fire.

۲

()

contents

SETTING UP YOUR WASHING MACHINE



 (\bullet)

WASHING A LOAD OF LAUNDRY

CLEANING AND MAINTAINING YOUR WASHING MACHINE



TROUBLESHOOTING AND INFORMATION CODES



CYCLE CHART



15 Drain

14 14

14

- 15 Flooring
- 15 Surrounding temperature

Water Supply

- 15 Alcove or closet installation
- 15 Installing your washing machine

Meeting installation requirements

Electrical supply and grounding

20 ENVIRONMENT

13 Checking the parts

- 21 Washing for the first time
- 21 Basic instructions
- 22 Using the control panel
- 25 Child lock
- 25 Sound off
- 25 Delay end
- 26 Drain Only Fuction
- 26 My cycle
- 27 Bubble wash
- 28 Air Wash

29 Using dry course

- 30 Washing clothes using the cycle selector
- 31 Washing clothes manually
- 31 Laundry guidelines
- 32 Detergent and additives information
- 32 Which detergent to use
- 33 Detergent drawer
- 33 Liquid Detergent (Selected models)
- 34 Drum Clean
- **35** Draining the washing machine in an emergency
- 36 Cleaning the debris filter
- 36 Cleaning the exterior
- 37 Cleaning the detergent drawer and drawer recess
- 37 Cleaning the water hose mesh filter
- 38 Repairing a frozen washing machine
- 38 Storing your washing machine
- 39 Check these points if your washing machine...
- 40 Information codes
- 41 Cycle chart
- 42 Fabric care chart
- 42 Protecting the environment
- 42 Declaration of conformity
- 43 Specifications

12_ contents

۲

()




setting up your washing

Be sure to have your installer follow these instructions closely so that your new washing machine works properly and so that you're not at risk of injury when doing laundry.

۲

CHECKING THE PARTS

Carefully unpack your washing machine, and make sure you've received all of the parts shown below. If your washing machine was damaged during shipping, or if you do not have all of the parts, contact Samsung Customer Service or your Samsung dealer.



* Bolt hole covers : The number of bolt hole covers depends on the model (3~5 covers).

setting up your washing machine _13

()

2

SETTING UP

۲

setting up your washir

MEETING INSTALLATION REQUIREMENTS

Electrical supply and grounding

Never use an extension cord. \mathbb{A} WARNING Use only the power cord that comes with your washing machine.

When preparing for installation, ensure that your power supply offers:

- AC 230V / 50Hz fuse or circuit breaker
- Individual branch circuit serving only your washing machine

Your washing machine must be grounded. If your washing machine malfunctions or breaks down, grounding will reduce the risk of electric shock by providing a path of least resistance for the electric current.

()

Your washing machine comes with a power cord having a three-prong grounding plug for use in a properly installed and grounded outlet.

۲

Never connect the ground wire to plastic plumbing lines, gas lines, or hot water pipes.

Improperly connecting the equipment-grounding conductor can result in electric shock. Check with a qualified electrician or serviceman if you are unsure if the washing machine is properly grounded. Do not modify the plug provided with the washing machine. If it does not fit the outlet, have a proper outlet installed by a qualified electrician.

Water Supply

Your washing machine will fill properly when your water pressure is 50 kPa ~ 800 kPa. Water pressure less than 50 kPa may cause water valve failure, not allowing the water valve to shut off completely. Or, it may take the washing machine longer to fill than what the controls allow, resulting in your washing machine turning off. (A fill-time limit, designed to prevent overflows/ flooding if an internal hose becomes loose, is built into the controls.)

The water taps must be within 120cm of the back of your washing machine for the provided inlet hoses provided to reach your washing machine.



Most plumbing supply stores sell inlet hoses of various lengths up to 305 cm long.

You can reduce the risk of leaks and water damage by:

- Making water taps easily accessible.
- Turning off taps when the washing machine is not in use.
- Periodically checking for leaks at water inlet hose fittings.



Before using your washing machine for the first time, check all connections at the water wing valve and taps for leaks.

14 setting up your washing machine

()

Drain

Samsung recommends a standpipe height of 65cm. The drain hose must be routed through the drain hose clip to the standpipe. The standpipe must be large enough to accept the outside diameter of the drain hose. The drain hose is attached at the factory.

()

Flooring

For best performance, your washing machine must be installed on a solidly constructed floor. Wood floors may need to be reinforced to minimize vibration and/or unbalanced loads. Carpeting and soft tile surfaces are contributing factors to vibrations and the tendency for your washing machine to move slightly during the spin cycle.

Never install your washing machine on a platform or poorly supported structure.

Surrounding temperature

Do not install your washing machine in areas where water may freeze, since your washing machine always retains some water in its water valve, pump, and hose areas. Frozen water in the lines can cause damage to belts, the pump, and other components.

Alcove or closet installation

To operate safely and properly, your new washing machine requires minimum clearances of:

Sides – 25 mm Top – 25 mm

۲

Rear – 50 mm Front – 465 mm

If both the washing machine and a dryer are installed together, the front of the alcove or closet must have at least 465 mm unobstructed air opening. Your washing machine alone does not require a specific air opening.

INSTALLING YOUR WASHING MACHINE

STEP 1

Selecting a location

Before you install the washing machine, make sure the location:

- Has a hard, level surface without carpeting or flooring that may obstruct ventilation
- Is away from direct sunlight
- Has adequate ventilation
- Will not be freezing (below 0 °C)
- Is away from heat sources such as oil or gas
- · Has enough space so that the washing machine doesn't stand on its power cord

setting up your washing

STEP 2


Removing the shipping bolts

Before installing the washing machine, you must remove all shipping bolts from the back of the unit.

 (\bullet)

1. Loosen all the bolts with the supplied wrench.

section of the hole. Repeat for each bolt.



- 4. Store the shipping bolts away safely in case you have to move the washing machine in the future.

Packaging materials can be dangerous to children; keep all packaging material (plastic \mathbb{A} WARNING bags, polystyrene, etc.) well out of the reach of children.

۲

16_ setting up your washing machine

()

STEP 3 Adjusting the Levelling feet

When installing your washing machine, ensure that the power plug, the water supply and the drain are easily accessible.

- 1. Slide the washing machine into position.
- 2. Level your washing machine by turning the levelling feet in and out as necessary by hand.
- **3.** When your washing machine is level, tighten the nuts using the wrench supplied with your washing machine.


STEP 4

()

Connecting the water and drain

Connecting the water supply hose

- Take the L-shaped arm fitting for the cold water supply hose and connect it to the cold water supply intake on the back of the machine. Tighten by hand.
- The water supply hose must be connected to the washing machine at one end and to the water tap at the other. Do not stretch the water supply hose. If the hose is too short, replace the hose with a longer, high pressure hose.
- 2. Connect the other end of the cold water supply hose to your sink's cold water tap and tighten it by hand. If necessary, you can reposition the water supply hose at the washing machine end by loosening the fitting, rotating the hose, and retightening the fitting.



For selected models with an additional hot water intake:

1. Take the red L-shaped arm fitting for the hot water supply hose and connect it to the hot water supply intake on the back of the machine. Tighten by hand.

۲

- **2.** Connect the other end of the hot water supply hose to your sink's hot water tap and tighten it by hand.
- 3. Use a Y-piece if you only want to use cold water.

01 SETTING UP

۲


setting up your washing machine

Connecting the water supply hose

1. Remove the adaptor from the water supply hose.

- First, using a '+' type screwdriver, loosen the four screws on the adaptor. Next, take the adaptor and turn part (2) following the arrow until there is a 5 mm gap.
- **3.** Connect the adaptor to the water tap by tightening the screws firmly while lifting the adaptor upwards. Turn part (2) following the arrow and connect (1) and (2).
- Connect the water supply hose to the adaptor. When you release part (3), the hose automatically connects to the adaptor making a 'click' sound.

After you have connected the water supply hose to the adaptor, ensure that it is connected correctly by pulling the water supply hose downwards.




Adaptor

Water supply hose

5 mm

Water tap

5. Connect the other end of the water supply hose to the inlet water valve at the rear of the washing machine. Screw the hose clockwise all the way in.



18_ setting up your washing machine

6. Turn on the water supply and ensure that no water leaks from the water valve, tap or adaptor. If there is a water leaks, repeat the previous steps.



()

Do not use your washing machine if there is a water leak. WARNING This may cause electric shock or injury.

. If the water tap has a screw type tap, connect the water supply hose to the tap as shown.

Use the most conventional type of tap for the water supply. In case the tap is square or too big, remove the spacing ring before inserting the tap into the adaptor.

Connecting the Aqua Hose (Selected models)

The Aqua Hose was invented for perfect leakage protection. It is attached to the water supply hose and automatically cuts off the water flow if the hose is damaged. It also displays a warning indicator.

Connect the water supply hose to the tap as shown. .



2 SETTING UP

۲






setting up your washing machine

Connecting the drain hose

The end of the drain hose can be positioned in three ways:


1. Over the edge of a wash basin: The drain hose must be placed at a height of between 60 and 90 cm. To keep the drain hose spout bent, use the supplied plastic hose guide. Secure the guide to the wall with a hook or to the tap with a piece of string to prevent the drain hose from moving.



- **2.** In a sink drain pipe branch: The drain pipe branch must be above the sink siphon so that the end of the hose is at least 60 cm above the ground.
- **3.** In a drain pipe: We recommend using a 65 cm high vertical pipe; it must be no shorter than 60 cm and no longer than 90 cm.



- minimum diameter 5 cm.
- minimum carry-away capacity 60 liter per minute.



STEP 5 Powering your washing machine

Plug the power cord into a wall sockets, an AC 230V / 50Hz approved electrical outlet protected by a fuse or circuit breaker. (For more information on electrical and grounding requirements, see page 14.)

ENVIRONMENT

۲

Please dispose of the packaging materials for this product in an "environmentally friendly" manner. For further detail, please contact your local area authority.

۲

20_ setting up your washing machine


washing a load of laundry

With your new Samsung washing machine, the hardest part of doing laundry will be deciding which load to wash first.

WASHING FOR THE FIRST TIME

Before washing laundry for the first time, you must run a complete empty cycle (i.e. no laundry).

- 1. Press the **Power** button.
- **2.** Add a little detergent to the detergent compartment (1) in the detergent drawer.
- 3. Turn on the water supply to the washing machine.
- 4. Press the Start/Pause button.



This will remove any water that might be left over in the machine from the manufacturer's test run.

Compartment ①: Detergent for prewash, or starch.

Compartment (II): Detergent for the main wash, water softener, pre-soaking agent, bleach and stain removal product.

To use liquid detergent, use the liquid detergent box (refer to page 33 of the manual for the corresponding model). Do not add powdered detergent into the liquid detergent box.

Compartment (Second): Additives, e.g. fabric softener or former (fill no higher than lower edge (MAX) of "A")

BASIC INSTRUCTIONS

۲

1. Load your laundry into the washing machine.

Do not overload the washing machine. To determine the load capacity for each type of washing laundry, refer to the chart on page 31-32.

- Make sure that laundry is not caught in the door, as this may cause a water leak.
 Washing datagant may remain in the front rubbar part of the washer offer a washer
 - Washing detergent may remain in the front rubber part of the washer after a wash cycle. Remove any remaining detergent, as they may cause a water leak.
 - Do not touch the door glass while your washing machine is running or it may be hot.
 - Do not open the detergent drawer or the debris filter while your washing machine is running or you might be exposed to hot water or steam.
 - Do not wash water-proofed items in normal cycle except outdoor care program.
- 2. Close the door until it latches.
- **3.** Turn the power on.
- 4. Add detergent and additives to the dispenser drawer.
- 5. Select the appropriate cycle and options for the load.

The Wash Indicator light will illuminate and the estimated cycle time will appear in the display. 6. Press the **Start/Pause** button. WASHING A LOAD OF LAUNDRY

۲


02

washing a load of laundry _21

washing a load of laundry.

۲

USING THE CONTROL PANEL



22_ washing a load of laundry

()

۲

۲

	Super Eco Wash - Low temperature Bubble wash. Outdoor Care - Use for outdoor wear such as mountain clothes,				
		s include functional technology finishes			
	and fibers such as spandex, stretch, and micro-fiber.				
	Baby Care - High temperature wash and extra rinses help to ensure that				
	little washing powder remains to mark your thin clothes. Wool - Only for machine-washable wool. A load should be less than 2.0 kg.				
	• The wool course washes the	laundry using gentle cradling actions.			
		radling and soaking actions are I fibers from shrinkage / distortion and			
		stop operation is not a problem.			
	Neutral detergent is recomme	ended for wool course, for improved			
	washing results and for impro				
		cle of this machine has been approved by washing of machine-washable Woolmark			
		that the products are washed according			
		on the garment label and those issued			
		rer of this washing machine, M1125 er issued by I.W.S. Nominee Co., Ltd.)			
	Drain Only - Turn the Cycle Selector to the Spin position, press the Spin				
	button repeatedly until "No spin(@)" light comes on, and then press the Start/Pause button to drain the water.				
PREWASH					
SELECTION BUTTON	Press this button to select pre-wash. Pre-wash is only available with: Cotton, Synthetics, Baby Care.				
4 DELAY END	Press this button repeatedly to cy options (from 3 hours to 19 hours	cle through the available Delay End			
		me when the wash cycle will be finished.			
5 TEMPERATURE SELECTION BUTTON	Press this button repeatedly to cy temperature options: (Cold Water	/cle through the available water [•] ⊕, 30 °C, 40 °C , 60 °C and 95 °C).			
6 RINSE SELECTION BUTTON	Press this button to add additional rinse cycles. The maximum number of rinse cycles is five.				
	Press the button repeatedly to cycle through the available speeds for the				
	spin cycle.				
7 SPIN SELECTION	WD0754	छ, 400, 800, 1200, 1400 rpm			
BUTTON	WD0752	छ, 400, 800, 1000, 1200 rpm			
	"No spin X" - The laundry remains in the drum and no spin cycle is				
	performed after the final drain.				

hbl

۲

۲

2011-9-19 15:55:39

washing a load of laundry

۲

8 DRYING BUTTON	 Pressing the button cycles through the following options. Cup Board \$\$\vec{v}\$ → Low Temp \$\$\$\$\$ → Iron \$\$\vec{a}\$\$ → Time Dry \$\$\$\$\$\$\$\$\$\$\$\$ (30min. →1:00 h → 1:30 h → 2:00 h → 2:30 h → 3:30 h → 4:00 h → 4:30 h) → Cup Board \$\$\$\$\$\$\$\$\$ Cup Board \$\$\$\$\$\$\$ → Use this cycle to dry loads such as cotton, underwear, and linen. Low Temp \$\$\$\$\$\$\$\$\$\$ - This cycle protects heat-sensitive items at a low drying temperature. Iron \$\$\vec{a}\$\$ - Finishes the dry cycle in a moist state appropriate for Ironing. Time Dry \$\$\$\$\$\$\$\$\$ -Dry the laundry for the specified period of time. You must avoid washing laundry that can't safely be dried as it may be deformed even at low temperatures. The Cup Board, Low Temp, Iron and Time Dry options detect the weight of the laundry in order to display an accurate drying time and dry them more completely. The drying conditions may differ depending on the type and the amount of laundry. Drying is not available for Eco Drum Clean, Air Wash, Outdoor Care and Wool courses. When you select the Drying course, the drying cycle time that appears on the display includes 17 minutes of spinning time.
9 INTENSIVE WASH SELECTION BUTTON	Press this button when the laundry is heavily soiled and needs to be washed intensively. The cycle time will be increased if the intensive wash is on.
10 ECO BUBBLE SELECTION BUTTON	 Eco Bubble selection is turned on as a default. Press the Eco Bubble option button once to deselect and the Bubble Generator OFF (shown on the panel), press it again to turn the function back ON. Some wash cycles must have Eco Bubble option ON (will show on the panel, and the Generator will turn on automatically). Other wash cycles do not need this option and automatically turn the Generator OFF. On many cycles, you can manually adjust this option, which will visibly affect wash time on the panel to achieve results (please see page 27 for more information).
11 START/PAUSE SELECTION BUTTON	Press to pause and restart a cycle.
12 MY CYCLE SELECTION BUTTON	Choose your favorite cycle including temperature, spin, soil level, option, etc.
13 POWER BUTTON	Press it once to turn your washing machine on, press it again to turn your washing machine off. If the washing machine is left on for more than 10 minutes without any buttons being touched, the power automatically turns off.

24_ washing a load of laundry

۲

۲

Child lock

The Child Lock function allows you to lock the buttons so that the wash cycle you've chosen can't be changed.


۲

Activating/Deactivating

If you want to activate or deactivate the Child Lock function, press the **Temp.** and **Rinse** buttons at the same time for 3 seconds. "Child Lock " will be lit when this feature is activated.

۲

When the Child Lock function is activated, only the **Power** button works. The Child Lock function remains on even after the power is turned on and off or after the disconnecting and reconnecting the power cord.




Sound off

The Sound Off function can be selected during all courses. When this function is selected, sound is turned off for all courses. Even if the power is turned on and off repeatedly, the setting is retained.

Activating/Deactivating

If you want to activate or deactivate the Sound Off function, press the **Spin** and **Option** buttons at the same time for 3 seconds. The "Sound Off 🕬" will be lit when this feature is activated.



Delay end

You can set the washing machine to finish your wash automatically at a later time, choosing a delay of between 3 to 19 hours (in 1 hour increments). The hour displayed indicates the time at which the wash will be finished.

- 1. Manually or automatically set your washing machine according to the type of laundry you are washing.
- 2. Press the Delay End button repeatedly until the delay time is set.
- **3.** Press the **Start/Pause** button. The "**Delay End** ⁽¹⁾" indicator will be lit, and the clock will begin counting down until it reaches the set time.
- 4. To cancel a Delay End function, press the **Power** button and then turn the washing machine on again.

۲

washing a load of laundry

Drain Only Fuction

When you want just drain water from washing machine, follow directions below.

()

- 1. Press the **Power** button.
- **2.** Turn the Cycle Selector to the Spin position.
- 3. Press the Spin button repeatedly until "No spin()" light comes on.
- 4. Press the Start/Pause button.

My cycle

Allows you to activate your custom wash (temperature, spin, soil level, etc.) with one button convenience.

By pushing the **My Cycle** button, press the My Cycle button to load and use the saved My Cycle options. The chosen course and option lights will flicker.

You can set all options as follows in the My Cycle mode.

- **1.** Turn the water supply on.
- 2. Press the Power button.
- 3. Select cycle using the Cycle Selector.
- 4. After cycle selection, set each option.

See the "Cycle Chart" on page 41 for available option settings with each cycle.

5. You can then store the selected cycle and options by pressing and holding the My Cycle button for longer than 3 seconds in My Cycle mode. The cycle and options you select will be displayed the next time you choose the My Cycle function.



۲

You can change the My Cycle settings by repeating the same process above. The last used setting will be displayed the next time you choose the My Cycle function.

If you press My Cycle and release it within 3 seconds, the previously saved course and options appear. If you press and hold My Cycle for 3 second or longer, the currently set course and options are saved and the LED blinks for 3 seconds.

26_ washing a load of laundry

۲

Bubble


Course	Bubble function	Canceling the bubble function
Cotton, Synthetics, 15' Quick Wash		Available
Super Eco Wash, Outdoor Care, Baby Care, Wool	Available	Not available

۲

• A different bubble function may be applied depending the course.

Eco Bubble selection is default. Press it once to deselect bubble option, press it again to select bubble option.

- 1. Open the door, place the laundry inside the wash tub and close the door.
- 2. Press the **Power** button.
- 3. Select a function.
- **4.** Place the appropriate amount of detergent and fabric softener into the corresponding compartments depending on the amount of laundry and close the detergent drawer.
 - Add the appropriate amount of detergent into the detergent compartment (II), and add the fabric softener to softener compartment (II) just under the fiber softener base line (MAX) of "A")
 - When the Prewash course is selected, add detergent into the prewash compartment ① as well.
 - To use liquid detergent, leave the liquid detergent box in the drawer(refer to "Liquid Detergent" section on page 33).



WASHING A LOAD OF LAUNDRY

۲

202

Do not add powdered detergent into the liquid detergent box.

- 5. Press the Start/Pause button.
 - Press the **Start/Pause** button to start the wash.
 - The amount of the laundry is automatically detected and the laundry is washed.
 - Once a washing machine operation begins, you cannot add or select the bubble function.

• Enough bubbles are generated with the specified amount of detergent.

- Please clean the debris filter frequently. Periodic cleaning helps generate sufficient bubbles.
- Depending on the detergent and the laundry, the bubbles may be absorbed and seem like a small quantity.
- Although bubbles are generated once the wash begins, it may take several minutes for users to see them.

۲

washing a load of laundry.

Air Wash

Air Wash can refresh laundry without using water owing to its powerful airing system. Clothing that can be refreshed includes woolen coats, cotton jumpers, sweaters and suits. [Two items or less (less than 1 kg)]

1. Open the door, place the laundry into the washing machine and close the door.

 (\bullet)

- 2. Press the Power button.
- 3. Select Air Wash by turning the Cycle Selector.

MODE	CYCLE TIME	
Deodorization	29 min	
Sanitization	59 min	

• When one of these options has been selected, no other button can be selected and you can only select the delay end time from between 3:00 – 19:00.

4. Close the door and press the Start/Pause button.



۲

- When there is water in the tub, **Air Wash** cannot be worked. Drain the water and select **Air Wash**.
- Press the Start/Pause or Power button to remove the laundry.
- Fragrance or dryer sheets can be used with Air Wash programs to add fragrance to your refreshed laundry (one sheet per one or two items).

Avoid Air Wash the following clothes:

- Sensitive clothes made of leather, mink, fur, silk, etc.
- Underwear trimmed with lace, 'glued' doll cushions, and dress suits may have their decorations loosened.
- Clothes trimmed with buttons can cause them to break.
- Starchy clothes can become deformed.
- Hard bedding such as a wooden pillows (neck-rest)
 - Pillows or blankets filled with plastic or starch rather than cotton
 Electric blankets

۲

- Furry blankets
- Bulky blankets
- Latex pillow

28_ washing a load of laundry

02 WASHING A LOAD OF LAUNDRY

()

USING DRY COURSE

Refer to the label of drying capacity and be sure to put in the clothes to the lower level than the marked line for the dried clothes of 4.0kg.

()

- 1. Open the door, put in the clothes and close the door again.
- Press the **Power** button and then press the **Drying** button.
 The standard course will be selected automatically.
 Drying is not available for Eco Drum Clean, Air Wash, Outdoor Care and Wool courses.
- 3. Select **Drying** button as follows. Drying Programs

Drying Type		Information	Max Load	Time (Max Load)
Auto Drying	Cupboard(र्छ)	Standard: Dries the laundry.	3.5kg	160min.
	Low Temp.(🌡)	Dries the laundry at a low temperature to protect the texture of the laundry.	2.0 kg	160min.
	Iron(르)	For leaving items partially damp so that it can be easily ironed	2.0 kg	30min.
Time Dr	ying(🖏)	You can select the appropriate drying time depending on the texture, quantity, and moisture.	4.0 kg	270min.

- For Auto Drying programs, this machine automatically displays Drying Time by sensing the weight of clothes before drying, and adjusting appropriately.
- For laundry weighing less than 3.0kg, use the Auto Dry. For laundry that weighs more, please use the Time Dry.
 - If both the spin and drying cycles are selected, the spin speed is automatically selected to enhance the drying efficiency.
 - When using the drying cycle, check if the water supply valve is opened.
 - When you select the Drying course, the drying cycle time that appears on the display includes 17 minutes of spinning time.
- 4. Put suitable amount of detergent and fiber softener in the detergent tray and close it again.

5. Press Start/Pause button.

- : It automatically performs an optimal function from washing to drying.
- The selected course can't be altered after the start of drying.
- If cold water is not supplied, drying will not be performed.

X Australian energy testing was undertaken using a 4kg load, Drying course+Intensive program.

()

washing a load of laundry.

Washing clothes using the cycle selector

Your new washing machine makes washing clothes easy, using Samsung's "Fuzzy Control" automatic control system. When you select a wash program, the machine will set the correct temperature, washing time, and washing speed.

۲

- 1. Turn on your sink's water tap.
- 2. Press the **Power** button.
- **3.** Open the door.
- 4. Load the articles one at a time loosely into the drum, without overfilling it.
- 5. Close the door.
- 6. Add detergent, softener, and pre-wash detergent (if necessary) into the appropriate compartments.

Pre-wash is only available when selecting the Cotton, Synthetics, Daily Wash, Baby care cycles. It is only necessary if your clothing is heavily soiled.

- Use the Cycle Selector to select the appropriate cycle according to the type of material: Cotton, Synthetics, 15' Quick Wash, Super Eco Wash, Outdoor Care, Baby Care, Wool, Hand Wash. The relevant indicators will illuminate on the control panel.
- **8.** At this time, you can control the wash temperature, the amount of rinses, the spinning speed, and the delay time by pressing the appropriate option button.
- **9.** Press the **Start/Pause** button and the wash will begin. The process indicator will light up and the remaining time for the cycle will appear in the display.

Pause Option

۲

Within 5 minutes of starting a wash, it is possible to add/remove laundry items.

1. Press the Start/Pause button to unlock the door.

The door cannot be opened when the water is too HOT or the water level is too HIGH.

2. After closing the door, press the Start/Pause button to restart the wash.

When the cycle is finished:

After the total cycle has finished, the power will turn off automatically.

- **1.** Open the door.
- 2. Remove laundry.

30_ washing a load of laundry

02 WASHING A LOAD OF LAUNDRY

()

Washing clothes manually

You can wash clothes manually without using the Cycle Selector.

- **1.** Turn the water supply on.
- 2. Press the **Power** button on the washing machine.
- **3.** Open the door.
- 4. Load the articles loosely into the drum one at a time, without overfilling it.

()

- 5. Close the door.
- **6.** Add detergent and, if necessary, softener or prewash detergent, into the appropriate compartments.
- 7. Press the Temp. button to select the temperature. (Cold water, 30 °C, 40 °C, 60 °C, 95 °C)
- 8. Press the **Rinse** button to select the required number of rinse cycles. The maximum number of rinse cycles is five. The wash duration is increased accordingly.
- 9. Press the Spin button to select the spin speed.(🕺 : No Spin)
- **10.** Press the **Delay End** button repeatedly to cycle through the available Delay End options (from 3 hour to 19 hours in one hour increments). The hour displayed indicates the time at which the wash will be finished.
- 11. Press the Start/Pause button and the machine will begin the cycle.

LAUNDRY GUIDELINES

()

Follow these simple guidelines for the cleanest laundry and the most efficient wash.

Always check the Care label on clothing before washing.

Sort and wash your laundry according to the following criteria:

- Care Label: Sort laundry into cottons, mixed fibres, synthetics, silks, wools and rayons.
- Colour: Divide whites and colours. Wash new colour items separately.
- Size: Placing items of different sizes in the same load will improve the wash action.
- Sensitivity: Wash delicate items separately, using the Delicate wash cycle for pure, new woollen items, curtains and silk articles. Check the labels on the items you are washing or refer to the fabric care chart in the appendix.

Emptying pockets

Before each wash, empty all the pockets of your laundry. Small, irregularly shaped hard objects, such as coins, knives, pins, and paperclips could damage your washing machine. Do not wash clothing with large buckles, buttons, or other heavy metal objects.

Metal on clothing may damage your clothing as well as the tub. Turn clothing with buttons and embroidered clothes inside out before washing them. If zips of pants and jackets are open while washing, the spin basket may be damaged. Zips should be closed and fixed with a string before washing.

Clothing with long strings may become entangled with other clothes damaging them. Be sure to fix the strings before starting the wash.

Prewashing cotton

Your new washing machine, combined with modern detergents, will give perfect washing results, thus saving energy, time, water and detergent. However, if your cotton is particularly dirty, prewash with a protein-based detergent.

nd a load of laur Was

Determining the load capacity

Do not overload the washing machine or your laundry may not wash properly. Use the chart below to determine the load capacity for the type of laundry you are washing.

Fabric Type	Load Capacity
Model	WD0754 / WD0752
Cotton - average/lightly soiled - heavily soiled	7.5 kg
Synthetics	3.0 kg
Outdoor Wear	2.0 kg
Wool	2.0 kg

• When the laundry is unbalanced ("UE" lights up on the display), redistribute the load. \mathbb{Z} If the laundry is unbalanced, the spin efficiency may be degraded.

 When washing Bedding or Duvet cover, the wash time may be lengthened or the spin efficiency may be degraded.

()

Make sure to insert brassieres (water washable) into a laundry net (to be purchased additionally).

- The metal parts of the brassieres may break through the material and damage the laundry. Therefore make sure to place them inside a fine laundry net.
- Small, light clothing such as socks, gloves, stockings and handkerchiefs may become caught around the door. Place them inside a fine laundry net.



CAUTION

Do not wash the laundry net by itself without other laundry. This may cause abnormal vibrations that could move the washing machine and cause an accident resulting in injury.

DETERGENT AND ADDITIVES INFORMATION

Which detergent to use

The type of detergent you should use is based on the type of fabric (cotton, synthetic, delicate items, wool), colour, wash temperature, and degree of soiling. Always use "low suds" laundry detergent, which is designed for automatic washing machines.

Follow the detergent manufacturer's recommendations based on the weight of the laundry, the degree of soiling, and the hardness of the water in your area. If you do not know how hard your water is, enquire at your local water authority.



Do not use detergent that has hardended or solidified as the detergent may remain in the rinse cycle. It may cause your washing machine to not rinse properly or result in the overflow becoming blocked.

Please note the following when using the Wool course.

- Use a neutral liquid detergent for wool only.
- When using a powder detergent, it may remain on the laundry and cause damage to the material (wool).

32_ washing a load of laundry

Detergent drawer

Your washing machine has separate compartments for dispensing detergent and fabric softener. Add all laundry additives to the correct compartment before starting your washing machine.

۲



Do not open the detergent drawer while your washing machine is running or you might be exposed to hot water or steam.

0


-A

- **1.** Pull out the detergent drawer on the left side of the control panel.
- 2. Add the recommended amount of laundry detergent directly into the detergent compartment (1) before starting your washing machine.

To use liquid detergent, use the liquid detergent box (refer to "Liquid Detergent" for the corresponding model).

- Do not add powdered detergent into the liquid detergent box.
- **3.** Add the recommended amount of fabric softener into the softener compartment (*) if required. DO NOT exceed the MAX FILL ((*) line.

Do NOT add any powder/liquid **detergent** to the softener caution compartment ().



4. When using the Prewash option, add the recommended amount of laundry detergent into the prewash compartment ①.

When washing large items do NOT use the following detergetnt types.

- Tablet and capsule type detergents
- Detergents using a ball and net


Concentrated or thick fabric softener and conditioner must be diluted with a little water before being poured into the dispenser (prevents the overflow from becoming blocked).

Be careful that the fabric softener does not overflow, when you close the detergent drawer after adding fabric softener into the rinse detergent compartment.

Liquid Detergent (Selected models)

To use liquid detergent, place the liquid detergent box into the main wash section of the detergent drawer and pour liquid detergent into the liquid detergent box.

- DO NOT fill above the MAX line.
 - When using powdered detergent, remove the liquid detergent box from the detergent drawer. Powdered detergent will not dispense with liquid detergent box.
 - After a wash, some liquid may remain in the detergent drawer.



MAX

washing a load of laundry _33

02 WASHING A LOAD OF LAUNDRY

۲

۲

cleaning and maintaining your washing machine

DRUM CLEAN


This course is a self-cleaning course that removes mould that may occur inside the washing machine.

- 1. Press the **Power** button.
- Turn the Cycle Selector to the ECO Drum Clean course.
 You can only use the Delay End function.
 - The water temperature during the ECO Drum Clean is set to 70 °C.



You cannot change the temperature.

- **3.** Place the appropriate amount of cleansing agent into the detergent compartment ^(III) and close the detergent drawer (when cleaning the drum using a cleansing agent).
 - Be sure to use the recommended cleansing agent for cleaning the drum.
 - There are powder-type and liquid-type drum cleansing agents. The liquid-type cleaning agent is only available with liquid detergent box (option).



- 4. Press the Start/Pause button.
 - If you press the **Start/Pause** button, the ECO Drum Clean course begins.
- Using the ECO Drum Clean course, you can clean the drum without using a cleansing agent.

 \triangle

۲

- Never use the ECO Drum Clean course when laundry is in the washing machine. This may result in damage to the texture or a problem with the washing machine.
- In the ECO Drum Clean course, never use normal detergent.
- Use only 1/10 of the amount of the drum cleansing agent recommended by the cleansing agent manufacturer.
- Since using a chlorine bleaching agent may discolour the product, be sure to use only oxygen bleaching agents.
- Powder-type cleansing agent: Use a [powder-type bleaching agent] or a [cleansing agent for drum cleaning only].
- Liquid-type cleansing agent: Use a [liquid-type oxygen bleaching agent] or a [cleansing agent for drum cleaning only].

34_ cleaning and maintaining your washing machine

The ECO Drum Clean Auto Alarm Function

- If the "ECO Drum Clean" indicator on the display and the lamp on the Cycle Selector are lit after a wash, it indicates that tub (drum) cleaning is required. In this case, remove the laundry from the washing machine, turn the power on, and clean the drum by performing the ECO Drum Clean course.
- If you do not perform the ECO Drum Clean course, the "ECO Drum Clean" indicator on the display and the lamp on the Cycle Selector are turned off. However, the "ECO Drum Clean" indicator on the display and the lamp on the Cycle Selector are turned on again after two washes are performed. However, this will not result in a problem with the washing machine.
- Although generally, the ECO Drum Clean Auto Alarm appears once a month or so, the frequency may differ depending on the number of times the washing machine is used.
- In case of the alarm, please also clean the debris filter (refer to "Cleaning the debris filter" section on page 36). Otherwise the performance of the bubble function may lower down.


DRAINING THE WASHING MACHINE IN AN EMERGENCY

- 1. Unplug the washing machine from the power supply.
- **2.** Open the filter cover by pressing down and pulling its handle.
- 3. Open the emergency drain cap by pulling it.

- **4.** Hold the cap on the end of the emergency drain tube and slowly pull it out about 15 cm.
- 5. Allow all the water to flow into a bowl.
- Remain water maybe more than you expected. Prepare larger bowl.
- 6. Reinsert the emergency drain cap and the drain tube.
- 7. Replace the filter-cover.



۲







cleaning and maintaining your washing machine _35

۲

2011-9-19 15:55:46

cleaning and maintaining your washing machine

CLEANING THE DEBRIS FILTER

We recommend cleaning the debris filter 5 or 6 times a year, or when the error message of "5E" is displayed. (Refer to "Draining the washing machine in an emergency" in the previous section.) If foreign substances accumulate debris filter, the performance of the bubble function will be degraded.

Before cleaning the debris filter, make sure to unplug the power cord.

1. Remove the remaining water first (refer to "Draining the washing machine in an emergency" on page 35.)

If you separate the filter without draining the remaining



Ø

()


- water, the remaining water may trickle out.Open the filter cover by using a key or coin.
- Unscrew the emergency drain cap by turning it to the left and drain off all the water.
- 4. Unscrew the debris filter cap.
- Wash any dirt or other material from the debris filter. Make sure the drain pump propeller behind the debris filter is not blocked.
- 6. Replace the debris filter cap.
- 7. Replace the filter cover.

Do not open the debris filter cap while the machine is running or hot water may flow out.

- Make sure to replace the filter cap after the filter cleaning. If the filter is out of the machine, your washing machine may malfunction or leak water.
 - The filter should be fully assembled after the filter cleaning.

CLEANING THE EXTERIOR


- 1. Wipe the washing machine surfaces, including the control panel, with a soft cloth using a nonabrasive household detergent.
- 2. Use a soft cloth to dry the surfaces.
- 3. Do not pour water onto the washing machine.






CLEANING THE DETERGENT DRAWER AND DRAWER RECESS

- 1. Press the release lever on the inside of the detergent drawer and pull the drawer out.
- 2. Remove the softener divider and the liquid detergent box(option) from the detergent drawer.



3. Wash all parts under running water.



- 4. Clean the drawer recess with an old toothbrush.
- **5.** Replace the softener divider and the liquid detergent box (option) by pushing it firmly into the drawer.
- 6. Push the drawer back into place.
- 7. To remove any remaining detergent, perform a rinse cycle without any laundry in the drum.



CLEANING THE WATER HOSE MESH FILTER

You should clean the water hose mesh filter at least once a year, or when the error message of "4E" is displayed:

- 1. Turn off the water supply to the washing machine.
- **2.** Unscrew the hose from the back of the washing machine. To prevent water from gushing out due to the air pressure in the hose, cover the hose with a cloth.
- **3.** Gently pull out the mesh filter from the end of the hose using a pair of pliers and rinse it under water until clean. Also clean inside and outside the threaded connector.
- 4. Push the filter back into place.
- 5. Screw the hose back onto the washing machine.
- 6. Make sure the connections are watertight and turn on the tap.

cleaning and maintaining your washing machine _37

03 CLEANING AND MAINTAINING

۲

()

cleaning and maintaining your washing machine

()

REPAIRING A FROZEN WASHING MACHINE

If the temperature drops below freezing and your washing machine is frozen:

- **1.** Unplug the washing machine.
- 2. Pour warm water over the tap to loosen the water supply hose.
- 3. Remove the water supply hose and soak it in warm water.
- 4. Pour warm water into the washing machine drum and let it sit for 10 minutes.
- **5.** Reconnect the water supply hose to the water tap and check if the water supply and drain are operating normal.

STORING YOUR WASHING MACHINE

If you need to store your washing machine for an extended time, it's better to drain and disconnect it. Washing machines can be damaged if water is left in the hoses and internal components before storage.

- 1. Select the **Cotton** cycle and add bleach to the bleach compartment. Then, push the **Quick Wash** button and run your washing machine through the cycle without a load.
- 2. Turn the water taps off and disconnect the inlet hoses.
- **3.** Unplug your washing machine from the electrical outlet, and leave your washing machine door open to allow air to circulate inside the tumbler.



۲

If your washing machine has been stored in below-freezing temperatures, allow time for any leftover water in your washing machine to thaw out before using it.

38_ cleaning and maintaining your washing machine

troubleshooting and information codes

CHECK THESE POINTS IF YOUR WASHING MACHINE...

۲

PROBLEM	SOLUTION
Will not start	 Make sure your washing machine is plugged in. Make sure the door is firmly closed. Make sure the water source tap(s) are turned on. Make sure to press the Start/Pause button.
Has no water or not enough water	 Turn the water tap on fully. Make sure the water source hose is not frozen. Straighten the water intake hoses. Clean the filter on the water intake hose.
Has detergent remaining in the detergent drawer after the wash cycle is complete	 Make sure your washing machine is running with sufficient water pressure. Make sure the detergent is added to the center of the detergent drawer.
Vibrates or is too noisy	 Make sure your washing machine is on a level surface. If the surface is not level, adjust the washing machine feet to level the appliance. Make sure that the shipping bolts are removed. Make sure your washing machine is not touching any other object. Make sure the laundry load is balanced.
The washing machine does not drain and/or spin	Straighten the drain hose. Eliminate kinked hoses.Make sure the debris filter is not clogged.
Door is locked shut or will not open.	• The door will not open until 3 minutes after the machine stops or the power turns off.

If the problem persists, contact your local Samsung Customer Service.

۲

04 TROUBLESHOOTING

۲

troubleshooting and information codes

INFORMATION CODES

If your washing machine malfunctions, you may see an information code on the display. If this happens, please check the table below and try the suggested solution before calling Customer Service.

۲

CODE SYMBOL	SOLUTION
dE	Close the door.Make sure the door is firmly closed.
4E	Make sure the source water tap is turned on.Check the water pressure.Clean the mesh filters of water hose.
5E	Clean the debris filter.Make sure the drainage hose is installed correctly.Clean the water hose mesh filter.
UE	• The laundry load is unbalanced. Redistribute the load. If only one item of clothing needs washing, such as a bathrobe or pair of jeans, the final spin result might be unsatisfactory and an "UE" error message will be shown in the display window.
cE/3E/Uc	Call the after-sales service.

For any codes not listed above, or if the suggested solution doesn't fix the problem, call your Samsung Service Centre or local Samsung dealer.

40_ troubleshooting and information codes

()

۲

cycle chart

CYCLE CHART

(• user option)

۲

PROGRAM		DETERGENT		Max Temp	Spin Speed(MAX) rpm		
	Max load(kg)	Pre-wash	wash	Softener	(°C)	WD0754	WD0752
Cotton	7.5	٠	yes	•	95	1400	1200
Synthetics	3.0	٠	yes	٠	60	1200	1200
Water Saving	7.5	٠	yes	٠	60	1400	1200
15' Quick Wash	2.0	-	yes	٠	40	800	800
Eco Drum Clean	-	-	-	-	70	400	400
Deodorization	1.0	-	-	-	-	-	-
Sanitization	1.0	-	-	-	-	-	-
Drying	4.0	-	-	-	-	-	-
Super Eco Wash	4.0	-	yes	٠	40	1200	1200
Outdoor Care	2.0	-	yes	٠	40	1200	1200
Baby Care	4.0	٠	yes	٠	95	1400	1200
Wool	2.0	-	yes	٠	40	800	800

۲

PROGRAM	Eco Bubble	Intensive	Delay end	Drying	Cycle time (min)
Cotton	٠	•	٠	٠	110
Synthetics	٠	٠	٠	٠	80
Water Saving	٠	٠	٠	٠	135
15' Quick Wash	٠	-	٠	٠	15
Eco Drum Clean	-	-	•	-	86
Deodorization	-	-	•	-	29
Sanitization	-	-	•	-	59
Drying	-	•	•	•	177
Super Eco Wash	•	٠	•	•	92
Outdoor Care	•	-	•	-	77
Baby Care	•	•	•	•	133
Wool	٠	-	٠	-	55

1. A cycle with a prewash takes approx. 15 minutes longer.

2. Course time in individual homes may differ from the values given in the table due to variations in the pressure and temperature of the water supply, the load and the type of laundry.

3. When the Intensive Wash function is selected, the cycle time is increased for each cycle.

05 CYCLE CHART

۲

cycle chart _41

appendix

FABRIC CARE CHART

The following symbols provide garment care directions. The care labels include four symbols in this order: washing, bleaching, drying and ironing (and dry cleaning when necessary). The use of symbols ensures consistency among garment manufacturers of domestic and imported items. Follow the care label directions to maximize garment life and reduce laundery problems.

۲

\square	Resistant material	$\overline{\overline{}}$	Can be ironed at 100 °C max
\Box	Delicate fabric		Do not iron
95 95	Item may be washed at 95 °C	A	Can be dry cleaned using any solvent
600 600	Item may be washed at 60 °C	P	Dry clean with perchloride, lighter fuel, pure alcohol or R113 only
10^{40} 10^{40}	Item may be washed at 40 °C	F	Dry clean with aviation fuel, pure alcohol or R113 only
30 30	Item may be washed at 30 °C	\otimes	Do not dry clean
1	Item may be hand washed	_	Dry flat
\bowtie	Dry clean only		Can be hung to dry
<u></u>	Can be bleached in cold water		Dry on clothes hanger
\bowtie	Do not bleach	$\overline{\mathbf{\cdot}}$	Tumble dry, normal heat
	Can be ironed at 200 °C max	\odot	Tumble dry, reduced heat
	Can be ironed at 150 °C max	\boxtimes	Do not tumble dry

PROTECTING THE ENVIRONMENT

- This appliance is manufactured from recyclable materials. If you decide to dispose of this appliance, please observe local waste disposal regulations. Cut off the power cord so that the appliance cannot be connected to a power source. Remove the door so that animals and small children cannot get trapped inside the appliance.
- Do not exceed the detergent quantities recommended in the detergent manufactures' instructions.
- Use stain removal products and bleaches before the wash cycle only when strictly necessary.
- Save water and electricity by only washing full loads (the exact amount depends upon the program used).

DECLARATION OF CONFORMITY

This appliance complies with European safety standards, EC directive 93/68 and EN Standard 60335.

42_ appendix

۲

۲

SPECIFICATIONS

ТҮРЕ			FRONT LOADING WASHING MACHINE		
DIMENSIONS		WD0754 / WD0752			
			W598mm X D600mm X H844mm		
WATER PRESSURE			50 kPa ~ 800 kPa		
WATER VOLUME			65 l		
NET WEIGHT			WD0754 / WD0752		
			70 kg		
WASH AND SPIN CAPACITY			7.5 kg [DRY LAUNDRY]		
DRY CAPACITY			4.0 kg		
POWER CONSUMPTION	MODEL		WD0754 /	WD0754 / WD0752	
	WASHING		230 V	150 W	
	WASH AND HEATING		230 V	2000 W	
	DRYING		230V	1600W	
	SPIN	MODEL	WD0754 /	/ WD0752	
		230V	350) W	
	PUMPING		34 W		
PACKAGE WEIGHT	MODEL		WD0754 / WD0752		
	PAPER		1.9 kg		
	PLASTIC		2.3 kg		
SPIN REVOLUTIONS	MODEL		WD0754	WD0752	
	rpm		1400	1200	

۲

The appearance and specifications of the product are subject to change without prior notice for purposes of product enhancement.

06 APPENDIX

۲

appendix _43

۲



۲

QUESTIONS OR COMMENTS?

Country	CALL	OR VISIT US ONLINE AT
AUSTRALIA	1300 362 603	www.samsung.com

Code No. DC68-02927D-01_EN

۲

۲