

INFORMATION FOR BUYERS:

To be used with either a lap-sash seat belt or an add-on accessory Child Harness by children whose shoulders are above the lower shoulder height marker with head restraint in lowest position (approximately 4 years of age) until child's shoulders reach the upper shoulder height marker with head restraint in highest position (approximately 6 to 8 years of age).

Suitable for use only with the Safe-n-Sound™ Protecta PLUS™ Harness Series 220/2010 or Babylove EzyGo Harness™ Series BL220/2010 Child Harnesses.

Britax**Safe-n-Sound**

Hi-Liner SG™

Child Booster Seat
Series Number: 4830/A/2010



Instructions for Installation & Use

**IMPORTANT:****KEEP THIS BOOKLET IN THE PLACE PROVIDED ON THE CHILD RESTRAINT**

Page

- 3 INTRODUCTION
- 4 WARNINGS
- 6 SHOULDER HEIGHT MARKERS AND A GROWING CHILD
- 7 SHOULDER HEIGHT MARKERS AND THE NEXT SEAT
- 8 SPECIAL FEATURES
- 10 SUITABLE FOR USE
- 11 HOW TO SETUP
- 13 HOW TO INSTALL
- 14 HOW TO USE
- 30 CARE & MAINTENANCE
- 31 HOW TO CLEAN
- 32 PRECAUTIONS
- 33 ACCESSORIES
- 34 PRE-INSTALLATION
- 35 PRE-INSTALLATION ANCHOR FITTING
- 37 FEATURES
- 38 IN CASE OF ACCIDENT

This Booster Seat is designed for use by children from approximately 4 years of age up to approximately 6 to 8 years of age in vehicles using a lap-sash seat belt or with a seat belt and Child Harness. It must not be used with just a lap only seat belt as the upper body of the child is not protected. This Booster Seat is fitted with the Versa-Tether™ catch that allows it to be used with a child harness.

Only the Safe-n-Sound™ Protecta PLUS™ Harness Series 220/2010 or Babylove EzyGo Harness™ Series BL220/2010 child harnesses are suitable for use with this product. No other Harness is suitable with this booster seat unless advised by Safe-n-Sound.

A child that is not tall enough to reach the lowest shoulder height marker in their seat with in-built harness will be too small for this booster seat. This booster seat should be used until the child no longer fits in the seat or the child can sit in the car's seat with their lower leg able to hang over the seat cushion.

This booster seat is not designed to be reclined.

CAREFULLY READ ALL THE INSTRUCTIONS FOR INSTALLATION.

IN THE EVENT OF DOUBT ABOUT THE METHOD OF INSTALLATION, CONSULT SAFE-N-SOUND OR A CHILD RESTRAINT FITTING STATION AUTHORISED BY A RELEVANT TRANSPORT AUTHORITY. IN NEW ZEALAND, CONTACT THE AGENT FOR THE VEHICLE.

THIS RESTRAINT MUST BE USED IN CARS WITH FORWARD FACING SEATS WITH A LAP-SASH SEAT BELT OR WITH A SEAT BELT AND CHILD HARNESS.

No child restraint can guarantee absolute protection from injury in every crash. However, to ensure that your child gets all the protection designed into the restraint PLEASE READ AND FOLLOW THESE INSTRUCTIONS EXACTLY.

Always store the instruction book under the base, for future reference.

WARNINGS

- Use the restraint exactly as shown in the instructions.
- Supervision of children is needed because they may be able to undo buckles and adjusters.
- **DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR.**
- Do not alter or modify this restraint. Use only recommended parts and accessories.
- Repairs must only be done by the manufacturer or agent.
- Do not allow the restraint to come into contact with polishes, oils, bleach and other chemicals.
- Destroy the restraint if it has been in a severe crash, even if no damage is visible.
- **DO NOT USE WITH JUST A LAP BELT.** You must use with lap-sash seat belt, or with a seat belt and child harness.
- The lap part of the seat belt must be firmly across the thighs and sash straps fitted diagonally across the chest and on the shoulder.
- If used with a child harness, the lap strap of the seat belt must be adjusted firmly first, and then the harness, so that the lap-strap is not lifted off the child's lap when the harness is adjusted.
- **DO NOT USE THIS RESTRAINT WITHOUT THE COVER.**
- **IF AN AIRBAG IS FITTED IN THE SEATING POSITION WHERE THE CHILD RESTRAINT IS TO BE FITTED, FOLLOW THE VEHICLE MANUFACTURER'S WARNINGS AND INSTRUCTIONS.**
- Regularly check the restraint components, straps and other fitments for correct function, cracking & condition. Seek prompt repair.
- Straps may be damaged by unsecured cargo in a collision. Secure or remove hazardous cargo before using this strap. Hatch-back or wagon: Do not use the child restraint where this strap may fall into a split in the seat back. Always attach hook and remove slack.


WARNINGS

- Securely stow all heavy objects, feeding bottles, cup holders, etc that could become missiles during an accident and cause injury to any occupant.
- The restraint should not be purchased or sold as a second hand item. It is recommended not to use child restraints older than 10 years as the protection in an accident may be reduced.
- **THIS RESTRAINT MUST BE ATTACHED TO A CHILD RESTRAINT ANCHORAGE POINT IN THE CAR. REFER TO CAR OWNER'S HANDBOOK FOR LOCATION OF ANCHORAGE POINTS. REFER TO A CHILD RESTRAINT FITTING STATION IF NO ANCHORAGE POINTS ARE IN THE MOTOR CAR.**
- **THIS RESTRAINT IS NOT SUITABLE FOR USE WHERE THE ANCHORAGE STRAP MAY FALL INTO A SPLIT IN THE SEAT BACK. (E.G. HATCHBACK OR WAGON).**
- Do not lift the seat by the headrest.
- Do not store in areas that may get hot, like in car boots, roof space, beside shed walls which get hot in summer. Do not place heavy items on top of the seat as this may distort the plastic.

WARNING:

DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR.

SHOULDER HEIGHT MARKERS & A GROWING CHILD



Height label will be behind the child's neck.

SMALLER CHILD

Shoulders must not be below the Lower Shoulder Height Marker when the headrest is the lowest position.

From approximately 4 years of age.



TALLER CHILD

Shoulders must not be above the Upper Shoulder Height Marker when the headrest is in the highest position.

To approximately 6 to 8 years of age.



Note:
These heights also apply if you are using a Child Harness with the booster seat.




SHOULDER HEIGHT MARKERS & THE NEXT SEAT

! IMPORTANT: Follow this advice.

Label A Smaller Child - Lower Marker


When moving from a child restraint with in-built harness the child's shoulders will be in line with or above the Lowest Marker (label A) with the headrest in the lowest position, if the child's shoulders are below this marker the child needs to be in a child seat with an in-built harness.



Label B Larger Child - Upper Marker

The seat can be used until the child's shoulders reach the Upper Marker (label B) with the headrest fully raised. Usually the shoulders will contact the bottom of the headrest, it is then time to move to the next form of restraint.

For maximum safety continue to use this seat as long as the child fits in the seat.



Next type of restraint that can be used in the car for your child.

When your child has outgrown the seat, you can then either use:



Just the car's lap-sash seatbelt.




Or you can use a Child Harness and lap seat belt. Lap seat belts can be dangerous without a Child Harness.



Or you can use a narrow booster seat suitable for children up to 8-10 years of age. An accessory Child Harness may be used.

SPECIAL FEATURES



SPECIAL FEATURES

1. Car's Anchor Fitting
2. Adjustable Height Headrest
3. Car Seat Belt
4. Padded Cover for Comfort
5. Booster Seat Belt path recess area
6. Booster Seat Belt path indicator
7. Pull-Out cup holder (1 each side)
8. Headrest Adjustment handle
9. Sash Guide (1 each side of headrest)
10. SLIDEGUARD™ Clip
11. Armrest (1 on each side)
12. Shoulder Height Markers
13. Shoulder slots for use with Child Harness
14. Upper Anchorage Strap Adjuster
15. Upper Anchorage Storage Band
16. Adjustable Upper Anchorage Strap
17. Attachment Clip

SUITABLE FOR USE

To be used with either a lap-sash seatbelt or an add-on accessory Child Harness by children whose shoulders are above the Lower Shoulder Height Marker with head restraint in the lowest position (approximately 4 years of age) until their shoulders reach the Upper Shoulder Height Marker with head restraint in the highest position (approximately 6 to 8 years of age).

Continue to use this child restraint until the child reaches this limit. Children are safest in a booster seat until their shoulders reach the Upper Shoulder Height Marker of the booster seat. Do not use this restraint until child's shoulders are above the Lower Shoulder Height Marker with the head restraint in the lowest position.

THIS RESTRAINT MUST BE USED IN CARS WITH FORWARD-FACING SEATS WITH A LAP-SASH SEAT BELT OR WITH A SEAT BELT AND CHILD HARNESS.

WARNING

- If your vehicle is not fitted with an anchor point, please contact a Safety Restraint Fitting Station authorised by the relevant State Government Body for correct fitment of the restraint. In New Zealand contact the agent for the vehicle. The upper anchorage strap must be attached to an anchorage point using an extension strap if necessary.
- **DO NOT USE WITH JUST A LAP BELT.** You must use with lap-sash seat belt, or with a seat belt and Child Harness.
- Do not use the restraint without the Upper Anchorage Strap attached.
- Do not use in a front seat, unless it has a child restraint anchorage point and your child is over 4 years of age or in accordance with the applicable Road Rules in your region.
- Do not use on any vehicle seat which faces sideways or rearwards.
- Only use Safe-n-Sound™ replacement covers for this Booster seat to ensure all safety information is provided.

HOW TO SETUP


ADJUSTING THE HEADREST

A. The headrest can be adjusted to lock into different height locations. This can be done with the child in the seat.




B. Hold backrest as shown and squeeze the headrest adjustment handle at the back of the headrest with the other hand, to move the headrest up or down.

 **Caution:** Keep hands away from gap at the back of the lower backrest whilst adjusting.




C. Adjust the headrest height so that the bottom of the sash guide is level with or just above your child's shoulder (but not more than 30mm above).



D. When the headrest is in the correct position let go of the headrest adjustment handle and ensure it has locked into place.

ADJUSTING THE BACKREST

The back rest pivots freely so as to match the car seat back angle. Move the restraint back until it is touching the car's seat back. If the vehicle seat back angle is adjustable put it in the normal upright mode.



HOW TO SETUP

ADJUSTING THE SLIDEGUARD™ CLIP POSITION

- A. Adjust the crotch straps for the SLIDEGUARD™ clip to the correct length for your child. It should be kept as low as possible to keep the lap portion of the seat belt engaged low-over the hips. Ensure the SLIDEGUARD™ clip does not push into your child's thighs as this may cause discomfort. **ALWAYS USE THIS DEVICE.**
- B. The crotch strap length adjusters can be found under the seat. Turn the booster over and adjust as shown.
- C. To change the length of the crotch strap, thread through the adjuster in the direction of the arrows shown.



Lower edge of SLIDEGUARD™ Clip, level with top of thighs.



! IMPORTANT :


You must adjust the crotch strap to the correct length for your child before installing the restraint as it cannot be adjusted in the car.

Always return the crotch strap to its original shorter length when using the seat with a smaller child. The SLIDEGUARD™ clip must always be positioned low down on your child's body - it will not connect correctly with the seat belt if it is too high. **DO NOT** attempt to remove or dismantle the crotch strap.

HOW TO INSTALL

INSTALLING INTO VEHICLE

- A. Position the restraint in the car forward facing in the chosen seating position. Adjust the headrest to the correct height for your child (refer to page 11). Ensure the seating position has a child restraint anchorage fitting. Refer to the car owner's handbook. If no fitting is provided refer to anchor fitting information on pages 34 to 36.
- B. Lengthen the upper anchorage strap by removing the excess strap from the storage band, then press the adjuster button (1) and pull the strap with the attachment clip (2). Hook the attachment clip to the anchor fitting. Make sure to remove any twists from the Upper Anchorage Strap.





- C. Tighten Adjustable Upper Anchorage Strap by pulling adjusting strap (3) to remove slack. Do not tighten causing the restraint base to lift off the vehicle seat.

! WARNING

Always attach hook and remove slack.

- D. Fold up excess strap and use storage band to neatly store away from child's reach and secure with the hook and loop storage strap.




HOW TO USE

USING LAP-SASH SEAT BELT WITHOUT CHILD HARNESS

- A.** Place the restraint Forward Facing in your car, ensuring it is pushed firmly into the car seat and the backrest touches the backrest of the car seat. Sit your child on the seat. Ensure the headrest is set to the correct height for your child (See page 11).



- B.** Position the lap-sash belt over the child ensuring the lap portion is positioned over the lap belt guides and under the armrests on both sides. Fit the sash portion of the belt through the sash guide on the headrest as shown.




ALWAYS USE THIS SASH GUIDE

HOW TO USE

- C.** Engage seat belt buckle and tongue ensuring there are no twists in the belt. If the seat belt buckle is adjustable, adjust the buckle as low as possible away from the child.

Note: In some vehicles, the vehicle headrest may need to be raised or even removed to allow the booster seat to sit correctly, the vehicle headrest may also interfere with the routing of the upper anchorage strap. If removed, store the vehicle headrest in a safe place.



- D.** Adjust lap and sash portion of seat belt firmly but comfortably across the child's lap and chest.

- E.** Fit the SLIDEGUARD™ clip to the lap belt. Ensure the bottom edge of the clip is in line with the thighs (see page 12).



- F.** If using an Inertia Reel Retractor seat belt, adjust the lap portion of the seat belt firmly around the child and restraint, then let the slack sash portion retract up into the sash retractor.

- G.** Fit the SLIDEGUARD™ clip with the logo facing forward to the Lap Belt.

ALWAYS USE THIS DEVICE



HOW TO USE

IMPORTANT:

Always ensure the seat belt is firmly fitted to the hips and thighs and the sash belt is diagonally across the chest.

The SLIDEGUARD™ clip must always be used when the child is using the booster seat as it ensures the lap belt is correctly positioned on the child's thighs and hips. A loose or poorly positioned lap belt can allow the lap belt to ride up into the abdomen and can cause serious injuries in a crash.

Do not place seat belt sash under the arm or behind the back.

WARNING :


A sash belt under arm or behind the back is dangerous.



HOW TO USE

Adjust headrest so it is close to the shoulders. Seat belt across the chest and through the sash guides.

Lap belt must always be firm on the thighs. The child should not slump or slouch.



NOTE:

Seat belt extenders should not be used if the seat belt is not long enough to fit around the child. If a seat belt extender is used then the seat belt buckle must not be in contact with the child.



TO REMOVE CHILD

Disengage seat belt tongue and buckle. Remove the lap portion of seat belt from the SLIDEGUARD™ clip, and remove belt from child. When Booster is not being used, secure in position, by engaging seat belt over the booster seat or store in a safe place.



HOW TO USE

USING WITH A CHILD HARNESS (PURCHASED SEPARATELY)


This booster seat is only suitable for use with Safe-n-Sound™ Protecta PLUS™ Harness Series 220/2010 or Babylove EzyGo Harness™ Series BL220/2010. Refer to the instruction book supplied with the Child Harness for full details of using and installing the Child Harness. When installing the Child Harness into the vehicle and booster seat, connect the upper anchorage strap to the Versa-Tether™ Catch on the Booster Seat's upper tether strap (as shown below).

If required, use the extension strap supplied with the child harness for all other instances to attach the harness to anchor points in the luggage area such as the vehicle floor or ceiling. Not suitable for most other styles of child safety harnesses.

INSTALLING SAFE-N-SOUND PROTECTA PLUS™ CHILD HARNESS INTO VEHICLE WITHOUT EXTENSION STRAP

Hook the Child Harness attachment clip (1) onto Versa-Tether™ Catch (2). Then hook attachment clip (3) onto anchor fitting. Ensure that none of the straps are twisted and not passing over any sharp edges.

1. Attachment Clip from Child Harness.
2. Versa-Tether™ Catch.
3. Booster seat Attachment Clip.
4. Anchor Fitting in the car.




NOTE:

Do not use the Versa-Tether™ catch on the Child Harness Clip (1). Versa-Tether™ catch (2) is only for use with a Child Harness.

HOW TO USE

INSTALLING SAFE-N-SOUND PROTECTA PLUS™ HARNESS WITH EXTENSION STRAP INTO VEHICLE

An adjustable extension strap is supplied with the Child Harness. Hook the Safe-n-Sound Protecta PLUS™ Harness clip first onto the extension strap catch, then hook the extension strap hook onto the Versa-Tether™ Catch on the Booster Seat's upper anchorage strap as shown below. Ensure that none of the straps are twisted or catching on sharp edges. Tighten the Booster Seat's upper anchorage strap (refer to page 13) then remove excess slack from the extension strap by pulling the adjuster strap as illustrated below.



HOW TO USE

Choosing Method of Installation

The Harness can be installed using either of the following methods.

Method 1 - Using a lap sash seat belt in conjunction with Gated Slide (provided with child harness) to convert to a lap belt.

Method 2 - Using lap seat belt.

Before installing the Child Harness determine which method of installation is required and follow instructions carefully.

REFER TO THE Safe-n-Sound™ Protecta PLUS™ Harness Series 220/2010 or Babylove™ EzyGo Harness™ Series BL220/2010 INSTRUCTIONS FOR FULL DETAILS ON HOW TO USE AND INSTALL THE CHILD HARNESS.

IMPORTANT:

The SLIDEGUARD™ clip must always be used when the child is using the booster seat with the child harness as it ensures the lap belt is correctly positioned on the child's thighs and hips. A loose or poorly positioned lap belt can allow the lap belt to ride up into the abdomen and can cause serious injuries in a crash.

INSTALLING THE HARNESS

Decide which seating position you are going to use and which seat belt type is installed in that position. If using a lap-sash seat belt then a Gated Slide must be used.


- A. Ensure the headrest is set to the correct height for your child (See page 11).
- B. Hook the attachment clip to the anchor fitting and tighten (refer page 13). Make sure to remove any twists from the upper anchorage strap. THIS UPPER ANCHORAGE STRAP MUST ALWAYS BE FITTED WHEN THE CHILD RESTRAINT IS USED IN A VEHICLE.

Hook attachment clip to the anchor fitting in the Car




HOW TO USE

- C. Lengthen the Child Harness using the adjuster under the cover (see the Child Harness instructions on the adjustment method). Press the Adjuster button (1) on the adjuster and pull the shoulder strap (2).




- D. Feed the left hand harness strap and attachment clip through the right hand slot of the booster seat.

Pass the left hand Strap and Attachment Clip through the right hand slot




HOW TO USE

- E. Hook the Attachment Clip from the Child Harness onto the Versa-Tether™ Catch, then pass the left hand harness strap through the left hand slot of the booster seat.



- F. Ensure the two shoulder straps are of equal length (as shown).



NOTE:
The straps must be in the slots provided in the headrest. The shoulder straps must be nearest to the child's shoulder's but not be lower than the child's shoulders.

HOW TO USE



USING LAP-SASH SEAT BELT WITH THE CHILD HARNESS (Using Gated Slide provided with Child Harness.)

Refer to the Child Harness instructions to fit Gated Slide and adjusting the car seat belt. Fit the Harness as detailed on page 18. Fit Gated Slide to both lap and sash belt as shown on pages 24 & 25. Ensure the Gated Slide is positioned under the armrest and close to the child, but not touching the child. Thread the converted lap-sash seat belt through the harness strap loops as shown left. Ensure there are no twists in the harness, cross strap and seat belt.

Where provided, fit the SLIDEGUARD™ clip to the lap part of the seat belt with the logo facing forward. The Lap Belt SLIDEGUARD™ clip should be used to reduce the risk of your child submarining (sliding forward on the base of seat).

IMPORTANT:
The Gated Slide must be removed from the seat belt if the booster seat and Child Harness are no longer used in the car to allow other users to use the seatbelt as a lap-sash seatbelt.


NOTE:
Seat belt extenders should not be used if the seat belt is not long enough to fit around the child. If a seat belt extender is used then the seat belt buckle must not be in contact with the child.




HOW TO USE

FITTING THE GATED SLIDE TO THE LAP-SASH SEAT BELT

A. Hold the lap and sash straps together and fold as shown right. Slide the inner strap into the Gated Slide followed by the outer strap.



B. The two straps should slide freely in the Gated Slide slot.



C. Repeat previous step A for the other slot in the Gated Slide.




HOW TO USE


D. Feed the straps through the Gated Slide to remove any slack.



E. There may be two types of Gated Slides available, Curved and Flat.



When fitting the Curved Gated Slide, the seat belt route can only go one way, as shown right.



HOW TO USE



USING LAP SEAT BELT WITH THE CHILD HARNESS

Fit the Child Harness as detailed on page 18. Thread the lap seat belt through the Child Harness strap loops as shown below. Ensure there are no twists in the Child Harness, cross strap and seat belt.

Important Note: Some vehicle seat belts are too short and you may experience some difficulty fitting the converted lap-sash around your child. If so, adjust the Gated Slide nearer to your child, ideally under the armrest and lap belt recess area, (ensure the Gated Slide does not touch your child). This should provide more belt length to fit your child, but if the belt still will not fit, try another location in the vehicle, e.g. side seat. If the vehicle belts are still too short, then contact the vehicle manufacturer for advice on longer seat belts.

NOTE: Seat belt extenders should not be used if the seat belt is not long enough to fit around the child. If a seat belt extender is used then the seat belt buckle must not be in contact with the child. Connect the Harness to the Versa-Tether™ Catch as detailed on page 18.


- A. With the child seated, place each of the Child Harness straps over each shoulder.
- B. Feed the right hand strap (loop end) into the cross strap loop to connect the two sides.
- C. Feed the adult belt (lap belt or converted lap/sash) through the harness loops, ensuring that the cross strap loop does not disconnect. Also ensure there are no twists in the Child Harness, cross strap and seat belt.



1. Right Hand Harness Strap
2. Left Hand Harness Strap
3. Cross Strap
4. Cross Strap Loop
5. Right Hand Harness Strap Loop
6. Cover Pad (not shown)
7. Storage Strap

HOW TO USE

- D. Engage the seat belt tongue to the buckle and adjust the seat belt to sit firmly but comfortably around the child's pelvis. The seat belt buckle should be located as low as possible below the child's hip.
- E. With the lap belt (or converted lap/sash) adjusted to be a firm fit on the child's thighs, then adjust the Child Harness to remove all slack in the shoulder straps but do not tighten. Once adjusted, further adjustments are necessary only to the upper extension straps and to accommodate the growth of the child.
- F. Finally, fold the free end of the adjuster strap, secure using the storage strap, then place it into the top of the adjuster cover as shown left.
- G. Lengthen the harness at any time as shown on page 21, by fully pressing the Adjuster Button (1) whilst pulling the shoulder strap (2) upwards.



WARNING

The lap position of the seat belt must be adjusted firmly first, and then the Child Harness, so that the belt is not lifted off the child's lap when the child harness is adjusted. The Child Harness does not need to be tight.

Some vehicle seat belts are too short and you may experience some difficulty fitting the converted lap-sash around your child. If so, adjust the Gated Slide nearer to your child, ideally under the armrest and lap belt recess area, (ensure the Gated Slide does not touch your child). This should provide more belt length to fit your child, but if the belt still will not fit, try another location in the vehicle, e.g. side seat. If the vehicle belts are still too short, then contact the vehicle manufacturer for advice on longer seat belts.

HOW TO USE

TO REMOVE CHILD

Disengage seat belt tongue and buckle, remove the lap portion of seat belt from the SLIDEGUARD™ clip (where provided) and remove Child Harness and belt from child. When Booster is not being used, secure in position, by engaging seat belt over the booster seat or store in a safe place.

NOTE:

It maybe easier to unthread the car seat belt out of the loops before lifting the child harness over the child's head.

Once the child is too large for the booster seat, the child harness can still be used and is a significant safety device for children in a lap only seat belt. Refer to the child harness instruction book.

IMPORTANT:

Use seat belt to hold the child restraint when not in use.

When Booster is not being used, secure in position, by engaging seat belt over the booster seat or store in a safe place.

WARNING:


DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR.



HOW TO USE

TO REMOVE RESTRAINT FROM VEHICLE

- If a Child Harness is used, feed seat belt out through Child Harness.
- Disconnect the attachment clip from the car whilst lifting the seat slightly to slacken the upper anchorage strap. This leaves the Child Harness fitted to the booster seat and allows the seat to be put back with no adjustment to the Child Harness if it is in the same vehicle).



CARE & MAINTENANCE

REGULAR CARE OF THIS RESTRAINT:

Please check the following items regularly to ensure the safety of your child:

- A. Check the webbing for fraying.
- B. Ensure there are no cracks in moulding or the plastic moulding.
- C. If any part of the restraint is cracked or broken, seek repair immediately or replace the child restraint.
- D. Clean the cover and the seat regularly.

HOW TO CLEAN

Use only mild soap and water with a moist cloth to clean all metal and plastic parts of the booster seat.

Do not use harsh cleaners, polishes, oils, bleach or other chemicals.

COVER

The booster seat has a cover made from flame retardant fabric and is removable for cleaning. Washing and care instructions are on the care label attached to the cover. Refer to the following pages for instructions on how to remove and replace the cover.






VERY IMPORTANT:

Only use this child restraint with the cover supplied or a manufacturer-authorized replacement cover with identical shoulder height markers.

HOW TO CLEAN

TO REMOVE COVER

- A. To remove main cover, unhook elastics at the rear of the seat and unhook plastic retainers from the front & sides of the seat.
- B. Where provided, feed the SLIDEGUARD™ clip through the slot in the cover.
- C. To remove the headrest cover, unhook elastics at the rear of the seat and remove the headrest cover.



Removing Headrest Cover

HOW TO CLEAN

TO REPLACE COVER

1. Align and fit headrest cover over seat and re-attach elastic loops at the rear of the seat in 4 places. Feed SLIDEGUARD™ clip through the cover.
2. Fix plastic retainers to the base at the front and sides of the seat.
3. Align and fit main cover over seat backing. Re-attach elastic loops at the rear of the seat in 6 places and 2 under the seat.
4. Align and fit the headrest cover. Re-attach the 4 elastic loops.
5. Ensure all loops and retainers are fastened on both left and right sides of seat.

Precautions to prevent reducing the safety offered by this booster seat.

1. Ensure the seat belt is used and fitted correctly. The lap belt must be on thighs and not the abdomen and the sash belt must be diagonally across the chest and over the shoulder at all times.
2. Ensure the child does not put the sash behind their back or under their arm- it is dangerous.
3. Do not use the seat belt in any other way other than following the seat belt path labels.
4. If you are using a child harness ensure that the lap belt is firm on the child's thighs and not on the abdomen. Do not tighten the Child Harness tether strap, just remove slack so that the lap belt is not lifted.
5. Ensure the child does not slouch or slump. Always use the SLIDEGUARD™ Clip to secure the lap belt is correctly positioned to prevent slumping.
6. Ensure you advise the child not to undo the seat belt buckle unless told to do so.
7. Do not cause the seat to be reclined in any way.

ACCESSORIES

MESSY MAT SEAT PROTECTOR INSTRUCTIONS

Place ribbed or pocket end of the Messy Mat seat protector on edge of car seat, smooth back toward seat join ('A') and fit in any excess Messy Mat into the join of the car seat ('A').

Hook and loop attachment referred in some instruction books, are no longer required to fit this model of Messy Mat seat protector.



CAUTION:

The pocket is only for small, light items. DO NOT overload the pocket with heavy, bulky items as this may damage the pocket or cause passengers to trip over them.

CUP HOLDER (1 EACH SIDE)

To open the cup holder, pull firmly and it will slide out and click into place.

IMPORTANT:

Only use for holding cups, bottles and drink cartons. Do not use for hot drinks. Ensure the cup holder contents cannot be crushed by the car door. Use of the cup holder may limit the seat space next to this restraint.



PRE-INSTALLATION


Consult the vehicle owner's handbook for location of anchorage fittings or anchorage points and the possible use of spacers. Some vehicles may have an anchor fitting fitted by the vehicle manufacturer. If anchorage points cannot be found refer to car manufacturer or local child restraint fitting station or traffic authority for optimum position of anchorage point and the use of spacers.

UPPER ANCHORAGE STRAP

! IMPORTANT WARNING: THE ATTACHMENT CLIP COVER MUST ALWAYS BE USED AS IT PREVENTS THE RISK OF INCORRECT FITMENT OF THE ATTACHMENT CLIP TO THE ANCHOR FITTING. ALWAYS ENSURE THAT THE ATTACHMENT CLIP IS CORRECTLY ENGAGED TO THE ANCHOR FITTING AND NOT HOOKED OR FITTED TO ANY OTHER OBJECT BEFORE EACH USE OF THE RESTRAINT. THIS IS ESPECIALLY IMPORTANT IN VEHICLES SUCH AS STATION WAGONS, VANS, HATCH BACKS OR VEHICLES WITHOUT A FIXED PARCEL SHELF, SINCE THE ANCHOR POINT IS USUALLY NOT VISIBLE.

IMPORTANT INSTALLATION NOTE:

In some vehicles the anchor fitting in the rear vertical panel can only be installed in one way. Refer to vehicle owner's handbook or a child restraint fitting station for the correct method.



The shaded areas of this diagram illustrate the possible locations of the anchor fitting. Within each shaded area is an anchor fitting showing the correct way to install the fitting. Ensure the anchor fitting is aligned as illustrated unless stated otherwise in the vehicle owner's handbook.


PRE-INSTALLATION ANCHOR FITTING

IF THE CAR IS FITTED WITH CHILD RESTRAINT ANCHORAGE POINT

Locate the anchorage point behind the rear seating position. (consult the car owners handbook for the location of the anchorage point). The anchorage point should be directly behind and central to the restraint. Remove thread plug from the parcel shelf/floor/roof, etc. and install anchor bolt and fitting as shown in Fig.1.

CAUTION: DO NOT OVERTIGHTEN ANCHOR BOLT. OVERTIGHTENING MAY FRACTURE OR BREAK BOLT. MAXIMUM TORQUE IS 20 N.M. (14.75 ft.lb.)

Note: Minimum of five full turns of anchor bolt is required before tightening force is applied.




IF THE CAR IS NOT FITTED WITH CHILD RESTRAINT ANCHORAGE POINTS

For Sedans only - Drill 9mm diameter hole in the parcel shelf on the centre line of the seating position as shown in Fig.3. Before drilling the hole, check the underside for accessibility. Install the anchor bolt as shown in Fig.2.

For vehicles other than Sedans - In Australia, consult your nearest child restraint fitting station or traffic authority for vehicle inspection to find the best, correct position for the placement of the anchorage point, and for the correct attachment bolt length and use of spacers. In New Zealand, consult the agent for the vehicle.

Note to Queensland purchasers: The installation of anchorage points must be approved by authorised officers appointed by Queensland Transport. Authorised officers can be sourced from all Queensland Transport Customer Service and Queensland Ambulance Service Centres.



PRE-INSTALLATION ANCHOR FITTING

ONLY USE A 5/16 UNC GRADE 5 BOLT. IF THE BOLT IS NOT THE CORRECT LENGTH THE CAR MANUFACTURER'S HAND BOOK CAN PROVIDE ADVICE ON THE CORRECT LENGTH BOLT.

WARNING

CHILD RESTRAINTS MUST NOT BE ATTACHED TO UNSOUND METAL OR TO WOOD, OR SYNTHETIC STRUCTURES. WHEN DRILLING 9 MM HOLE DO NOT DRILL THROUGH FUEL LINES, FUEL TANKS, ELECTRICAL WIRING, OR RADIO SPEAKERS.

WEBBING STRAPS MUST BE PROTECTED FROM SHARP CORNERS AND EDGES. THE ANCHOR FITTING MUST BE USED ONLY AS DESCRIBED ABOVE. IT MUST NOT BE HOOKED ONTO ANY OTHER OBJECT.



Note: Marking on the top of a Grade 5 Bolt.



Front of Vehicle




Fig.3. Centre line of seating position

CAR INSTALLATION ACCESSORIES (From retailers of Safe-n-Sound products)

EXTRA ANCHOR KITS: Available for using the restraint in additional cars.

Re-order no: 0038

EXTENSION STRAPS: May be required for cars without a fixed parcel shelf.

Re-order no: 0035 (length 300mm) or 0036 (length 600mm)

GATED 3-BAR SLIDE (Locking clip): For converting lap-sash seat belt to lap belt, for use with a Child Harness. May be required for a second car. Re-order no: 0215.

FEATURES

- Exclusive Safe-n-Sound SLIDEGUARD™ Clip. The SLIDEGUARD™ Clip is a life saving device that prevents your child from sliding under the lap-belt (submarining) during impact, thus minimising the risk of abdominal injury.
- Hi-Liner SG™ is the first Expandable Booster Seat designed with slots in the seat cover and shell. Hi-Liner SG is compatible with Safe-n-Sound Protecta PLUS™ Harness for added safety.
- Deep side wings and EPS foam liner provides additional protection in a side impact accident.
- Secured with Tether to the Vehicle Anchor Point to provide superior stability in car.
- One hand adjustable headrest is simple to change height to comfortably fit child's height.
- The red colour coded seat belt guides indicate the path and positioning of seat belt for ease of use.
- Arm rests provide a guide for seat belt positioning and extra comfort
- Retractable cup holders designed to hold bottles and cans
- Includes Messy Mat to protect car upholstery

IN CASE OF ACCIDENT

If your restraint has been involved in a severe crash, you should destroy the restraint even if no damage is obvious. Some insurance companies offer vehicle insurance which covers or partially covers the replacement of your child restraint. Contact your insurance company for further details. Your insurance company may require you to keep the child restraint for assessment, **but do not use the child restraint after a severe crash**. To assist you in making an accident insurance claim cut the following statement and include it with your claim.

NOTICE TO INSURANCE COMPANY CHILD RESTRAINT INVOLVED IN AN ACCIDENT

All Safe-n-Sound child restraints are manufactured to Australian/New Zealand Standards AS/NZS1754-2010 which require us to advise users of child restraints to "Destroy the entire restraint if it has been in use in a severe crash, even if no damage is obvious". The joint Australian/New Zealand Standards committee CS/85 advise that this statement applies whether a child was in the child restraint or not. A severe crash, we consider as being one where the main body structure of the vehicle is distorted.

There is no method of determining if the restraint has been damaged and we concur with the Australian/New Zealand Standards in recommending destruction of the child restraint.

This notice is to advise you of the requirements of the Australian/New Zealand Standards and our obligation in complying with the standards.

Please assist the owner of this restraint in their claim.

AUSTRALIA

Britax Childcare Pty. Ltd.
A.B.N 55 006 773 600

Head office and registered address

99 Derby Road, Sunshine, Victoria 3020.
PO Box 147 Sunshine, Victoria 3020.

Customer Service 1300 303 330

Email au-custserv@britax.com

www.britax.com.au

NEW ZEALAND

Britax Childcare (NZ) Ltd.
Customer Service 0508 688 822

Email nz-custserv@britax.com

www.britax.co.nz



IN CASE OF ACCIDENT

CRASH EXCHANGE

We would never want you to experience an accident, but unfortunately accidents do happen. If you experience an accident you may be eligible for a free replacement.

The Safe-n-Sound Crash Exchange Program is a voluntary program designed to ensure that our children are safe and that any seat that may have experienced a severe crash is taken out of the market.

There is no method of determining if the restraint has been damaged in a severe crash, so the restraint should be destroyed as the crash may reduce the child restraints ability to perform.

Since its inception in 2006, the Crash Exchange program has helped 100's of families ensure that their children have new restraints and that the restraints are not sold second hand placing others at risk.

Our Crash Exchange Terms and Application form are accessible on our website. Please visit www.britax.com.au for further information.





AUSTRALIA

Britax Childcare Pty. Ltd.
A.B.N 55 006 773 600

Head office and registered address

99 Derby Road, Sunshine, Victoria 3020.
PO Box 147 Sunshine, Victoria 3020.

Customer Service 1300 303 330

Email au-custserv@britax.com

www.britax.com.au

NEW ZEALAND

Britax Childcare (NZ) Ltd.

Customer Service 0508 688 822

Email nz-custserv@britax.com

www.britax.co.nz

INTERNATIONAL ENQUIRIES

Contact your local Distributor.

The Safe-n-Sound, Hi-Liner & Protecta PLUS trademarks are the property of Britax Childcare Pty. Ltd. (Australia).

The Britax trademark is the property of Britax Excelsior Limited (UK).

The Babylove & EzyGo Harness trademarks are the property of Nursery Elegance Pty. Ltd. (Australia).

We reserve the right to alter this product without notice.

© 1995-2010 Britax Childcare Pty. Ltd. This product is covered by Australian and overseas patent applications. Patents pending.