

Retractable Hose Reel



Instruction Manual

Installation, Spare Parts, Care & Troubleshooting 1110H – Product Dimensions(mm): W:330 H:300 L:170 Weight: 4.42kg



Introduction

Thank you for purchasing this HOLMAN Retractable Hose Reel. This product uses a 12mm reinforced hose for added strength and durability, and includes a multi-function hose gun. (Hose Gun styling is subject to change)

For your information, please read these installation instructions before using the Retractable Hose Reel. Please keep all instructions and refer to them when necessary.

Glossary



Retractable Hose Reel - Instruction Manual



Please note that if you are attaching your hose reel to a wooden post, you will not require the wall plugs as the coach bolts screw directly into wood.

Take the wall plugs (supplied with the hose reel) and measure the correct drill bit width to use. It is recommended that you drill slightly undersize as masonry materials all have different properties and this will ensure the wall plugs have a secure fit.

As a guide only, the wall plugs for the 10m hose reel are 7.7mm in diameter, suitable to hammer into a 8mm drilled hole.

It is very important to use the correct size drill bit, so a very secure fit of the wall bracket is made before installing the Retractable Hose Reel.

When ready drill all four holes, then hammer the wall plugs gently into your wall (if attaching to a wall).

IMPORTANT - DO NOT LEAVE TAP ON. TURN TAP OFF AFTER USE.



Drill Bit

Plug

Bolt

Retractable Hose Reel - Instruction Manual



Care & Troubleshooting



You will find an indication sticker 1 metre before the maximum length. Do not pull the hose past this point.



When walking the hose back to the unit, turn off the tap, press the lever on the watering gun to release the water pressure in the hose. This makes the retraction to the hose reel a lot easier and prolongs the life of your hose reel.

Fully Extended Hose Not Retracting

If the hose retraction wheel is stuck and the hose is fully extended, the wheel still has movement past this point. Grip the hose close to the guide hole and gently pull. The retraction wheel will give you enough movement to unlock itself before you slowly allow the auto retraction wheel to wind the hose back into the unit.

Warnings

- Do not leave the water turned on with the hose under pressure when not in use.
- Always turn the water off and draw the water from the hose after use.
- Do not attempt to pull hose reel apart.

Spare Parts



To order spare parts please call our customer service team on 1300 716 188.

Should you have any questions about this product or its operation please telephone our customer service helpline on 1300 716 188 or visit www.holmanindustries.com.au Holman offer a 2 year replacement warranty from the original date of purchase. To claim warranty the product must be returned to the place of purchase with a copy of the original receipt.

We will honour all statutory guarantees that this product is of acceptable quality (including that it is fit for purpose).



HOLMAN INDUSTRIES 11 Walters Drive, Osborne Park, Western Australia 6017. Tel: 08 9204 1011 Fax: 08 9204 1013 Web: www.holmanindustries.com.au